

# DUMP-LOK<sup>®</sup>

A BLUE RIBBON SAFETY PRODUCT

## INSTALLATION INSTRUCTIONS



### 1 CHOCK WHEELS, RAISE **EMPTY** BED

Set Dump-Lok on truck frame, pushing firmly so the top and bottom plates make full contact



### 2 PLACE SAFETY CHAIN AROUND FRAME

Place chain around frame or cross member. Slide chain through key slot hole and tighten/lock chain.



### 3 REPEAT STEPS

Repeat steps 1-2 for opposite side of truck.

### 4 LOWER DUMP BED

Slowly and carefully lower the dump bed to secure the Dump-Loks.



**DO NOT "POWER DOWN" THE  
DUMP BOX! THIS CAN DAMAGE  
THE DUMP-LOK.**

**BLUERIBBON  
SAFETY**

MANUFACTURED AND DISTRIBUTED BY

**takt**

For more information: [WWW.TAKTLLC.COM](http://WWW.TAKTLLC.COM)